



Reading Technologies, Inc.

PERF-25 Maintenance Log

| | |
|---------|--|
| Shop | |
| Address | |
| Contact | |
| Phone | |

| Model Number - Dryer | Location | Check Date | Check Date | Check Date | Check Date | Check Date | Check Date | Install Date | Check Purge Air, Moisture Indicator, and Remarks |
|-------------------------------|----------|-------------|-------------|-------------|-------------|-----------------|---------------|--------------|--|
| PERF-25-TC | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| Model Number - Filter/Stage # | Location | Change Date | Change Date | Change Date | Change Date | Change Interval | Repl. Element | Install Date | Check Drain & Remarks |
| PERF-25-PF, Stage 1 | | | | | | 6 months | 3P-060* | | |
| PERF-25-PF, Stage 2 | | | | | | 6 months | 3C-060* | | |
| PERF-25-AF | | | | | | 6 months | 3C-060* | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

* PERF-25-MK; maintenance kit, consists of the three (3) replacement elements.
 PERF-25-RK; repair kit, consists of the three (3) replacement elements, desiccant, screen fittings, and moisture indicator paper.
 PERF-25-TC; tower change-out kit, consists of two (2) pre-packed desiccant towers with fittings.
 PERF-25-TCMK; tower change-out maintenance kit; consists of two (2) pre-packed desiccant towers with fittings, and replacement elements.

For Replacement Kits/Parts, contact Reading Technologies, Inc. at 800-521-9200 for a distributor near you.